

# **Installation Guide**

For S-link External Switch Interface 8730B, 8730S



DOCUMENT ID: 2071

**REVISION: 5** 

**DATE: 2024** 

LANGUAGE: EN



### **Contents**

### 

### **Warnings and Safety**

MC\_0800

It is essential to follow all instructions within this document to avoid potential personal injury, death, or damage to existing products in the vessel, the vessel's hull integrity, and including this product during installation or operation. Failure to follow instructions within this document will render all warranties given by Sleipner Motor as VOID.

Warnings and situations requiring extra caution are outlined in the documentation. Take extra consideration when warnings are outlined.



#### WARNING

Indicate a potentially hazardous situation that, if not avoided, could result in death or severe injury.

1

#### CAUTION

Indicates a potentially hazardous situation that could result in minor or moderate injury or critical damage to vessel integrity if not avoided.

MC\_0020

#### General:

- The installer must read this document to ensure necessary familiarity with the product before installation.
- Directions outlined in this document cannot be guaranteed to comply with all international and national regulations, including but not limited to health and safety procedures. It is the installer's responsibility to adhere to all applicable international and national regulations when installing Sleipner products.
- This document contains general installation guidelines intended to support experienced installers. Contact professional installers familiar with the vessel and applicable regulations if assistance is required.
- If local regulation requires any electrical work to be performed by a licensed professional, seek a licensed professional.
- When planning the installation of Sleipner products, ensure easy access to the products for future service and inspection requirements.

#### For Sleipner S-Link™ systems:

MC\_0105

- When installing an S-Link™ system, connect ONLY original Sleipner S-Link™ products or other authorized control equipment directly to the S-Link™ bus. When connecting non-authorized third-party equipment, it must always be connected through a Sleipner-supplied interface product.
- Any attempt to directly control or connect to the S-Link™ control system without a designated and approved interface from Sleipner will
  void all warranties and responsibilities of the connected Sleipner products. If you interface the S-Link™ bus by agreement with Sleipner
  through a designated Sleipner-supplied interface, you are still required to install at least one original Sleipner control panel to enable efficient
  troubleshooting if necessary.


#### For S-Link External Switch Interface:

MC\_0367


- The 8730 external switch interface allows the use of mechanical foot switches or other normally open switches to control a S-link bow thruster. In addition it allows for connecting the 8980/8985 radio remote control. When not in use or when leaving the boat, turn the control device off.
- The 8730 sends proportional thrust on the S-link bus. This is 70% as default. This value can be changed on an PJC212, PJC211, PJC222 or PJC221 panel. See manual of the panel for more details.
- If you have two thrusters bow and stern, then you need two 8730. One 8730B for bow and one 8730S for stern. You can change instance of 8730 B & S with a panel, see manual for panels for how to changing instance of 8730 B & S Never run the thruster while out of water.
- Any attempt to directly control or at all connect into the S-link control system without the designated and approved interface, will render all warranties and responsibilities for the complete line of Sleipner products connected void and null.


Connect the (foot) switches according to the wiring diagram(s).

- 1. To connect the optional radio remote, first cut the wires close to the plastic connector on the "bow" connection lead according to Fig. 1. Strip the wires properly and connect to the 8730 according to the wiring diagram(s). Do the same with the "stern" wires if needed.
- Mount the 8730 in a place where it will be protected from direct and condensed water ingress. Use cable ties or other suitable means of mounting.
- 3. Plug the S-link Spur cable into the green connector at the rear of interface box. Twist the locking ring on the connector clockwise to secure connector.




### 8730B Wiring Diagram







**207**I

# 8730B Wiring Diagram - With Touch Panel



## 8730S Wiring Diagram






MG\_0760

The 8730 needs to be activated for the switch inputs to work. Connect the control signals to the 4 pin connector as shown on wiring diagram below.

- Solution 1: Use a control panel to activate 8730 by turning the panel ON. When the last panel are turned OFF by time-out or OFF button the 8730 is deactivated. Preferred solution.
- Solution 2: By connecting a wire from pin 1 to pin 6 on the 6 pin connector, the 8730 will be activated and stay activated all the time when there is power on the S-Link (see wiring diagram below).

(NB: Solution 2 cannot be used with an retract thruster or Automatic Main Switch. This will prevent the retract to go inn and the AMS will not be able to turn off.)




MG\_0761

### Sample S-link System Setup


MC\_0736

MG\_0328

MC\_0736



# Wiring Example: Sleipner Retract Thruster and 'on-off' Thruster Combined



MG\_0762

Find your local professional dealer from our certified worldwide network for expert service and support. visit our website www.sleipnergroup.com/support

### **Product Spare Parts and Additional Resources**

MC 0024

For additional supporting documentation, we advise you to visit our website www.sleipnergroup.com and find your Sleipner product.

### **Warranty Statement**

MC\_0024

- Sleipner Motor AS (The "Warrantor") warrants that the equipment (parts, materials, and embedded software of products) manufactured by the Warrantor is free from defects in workmanship and materials for purpose for which the equipment is intended and under normal use and maintenance service (the "Warranty").
- 2. This Warranty is in effect for two years (Leisure Use) or one year (Commercial and other Non-leisure Use) from the date of delivery/purchase by the end user, with the following exceptions;
  - (a) For demonstration vessels, or vessels kept on the water, the dealer is considered as the end user from 6 months after their launch of the vessel:
  - (b) The warranty period starts no later than 18 months after the first launch of the vessel.
  - Please note that the boat manufacturer and dealer must pay particular attention to correct maintenance and service both by the products manuals as well as general good practice for the location the boat is kept in the period the boat is in their care. In cases where the 6 and 18 months grace periods for boat builders and dealers are passed, it is possible to obtain a full warranty upon inspection and approval of the warrantor or such representative.
- 3. Certain parts, classified as wearable or service parts, are not covered by the warranty. A failure to follow the required maintenance and service work as described in the product manual render all warranty on parts or components directly or indirectly affected by this void. Please also note that for some parts, time is also a factor separately from actual operational hours.
- 4. This Warranty is transferable and covers the equipment for the specified warranty period.
- 5. The warranty does not apply to defects or damages caused by faulty installation or hook-up, abuse or misuse of the equipment including exposure to excessive heat, salt or fresh water spray, or water immersion except for equipment specifically designed as waterproof.
- 5. In case the equipment seems to be defective, the warranty holder (the "Claimant") must do the following to make a claim:
  (a) Contact the dealer or service centre where the equipment was purchased and make the claim. Alternatively, the Claimant can make the claim to a dealer or service centre found at www.sleipnergroup.com. The Claimant must present a detailed written statement of the nature and circumstances of the defect, to the best of the Claimant's knowledge, including product identification and serial nbr., the date and place of purchase and the name and address of the installer. Proof of purchase date should be included with the claim, to verify that the warranty period has not expired.
  - (b) Make the equipment available for troubleshooting and repair, with direct and workable access, including dismantling of furnishings or similar, if any, either at the premises of the Warrantor or an authorised service representative approved by the Warrantor. Equipment can only be returned to the Warrantor or an authorised service representative for repair following a pre-approval by the Warrantor's Help Desk and if so, with the Return Authorisation Number visible postage/shipping prepaid and at the expense of the Claimant.
- 7. Examination and handling of the warranty claim:


8


- (a) If upon the Warrantor's or authorised service Representative's examination, the defect is determined to result from defective material or workmanship in the warranty period, the equipment will be repaired or replaced at the Warrantor's option without charge, and returned to the Purchaser at the Warrantor's expense. If, on the other hand, the claim is determined to result from circumstances such as described in section 4 above or a result of wear and tear exceeding that for which the equipment is intended (e.g. commercial use of equipment intended for leisure use), the costs for the troubleshooting and repair shall be borne by the Claimant;
- (b) No refund of the purchase price will be granted to the Claimant, unless the Warrantor is unable to remedy the defect after having a reasonable number of opportunities to do so. In the event that attempts to remedy the defect have failed, the Claimant may claim a refund of the purchase price, provided that the Claimant submits a statement in writing from a professional boating equipment supplier that the installation instructions of the Installation and Operation Manual have been complied with and that the defect remains.
- 8. Warranty service shall be performed only by the Warrantor, or an authorised service representative, and any attempt to remedy the defect by anyone else shall render this warranty void.
- 9. No other warranty is given beyond those described above, implied or otherwise, including any implied warranty of merchantability, fitness for a particular purpose other than the purpose for which the equipment is intended, and any other obligations on the part of the Warrantor or its employees and representatives.
- 10. There shall be no responsibility or liability whatsoever on the part of the Warrantor or its employees and representatives based on this Warranty for injury to any person or persons, or damage to property, loss of income or profit, or any other incidental, consequential or resulting damage or cost claimed to have been incurred through the use or sale of the equipment, including any possible failure or malfunction of the equipment or damages arising from collision with other vessels or objects.
- 11. This warranty gives you specific legal rights, and you may also have other rights which vary from country to country.

**Patents** 

MC\_0024

At Sleipner we continually reinvest to develop and offer the latest technology in marine advancements. To see the many unique designs we have patented visit our website www.sleipnergroup.com/patents






© Sleipner Group, All rights reserved The information given in the document was right at the time it was published. However, Sleipner Group cannot accept liability for any inaccuracies or omissions it may contain. Continuous product improvement may change the product specifications without notice. Therefore, Sleipner Group cannot accept liability for any possible differences between product and document.

Learn more about our products at www.sleipnergroup.com



#### **SLEIPNER MOTOR AS**

P.O. Box 519

N-1612 Fredrikstad

Norway

www.sleipnergroup.com

Made in Norway